



DTC P0404: EGR Valve Circuit Range/ Performance Problem

NOTE: Before you troubleshoot, record all freeze data and any on-board snapshot, and review the general troubleshooting information (see page 11-3).

1. Turn the ignition switch ON (II).
2. Clear the DTC with the HDS.
3. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on, then let it idle.
4. Do the EGR TEST in the INSPECTION MENU with the HDS.


Is the result OK?

YES—Intermittent failure, system is OK at this time. Clean any carbon build-up on the EGR valve with throttle plate and induction cleaner. ■

NO—Go to step 5.

5. Turn the ignition switch OFF.
6. Disconnect the EGR valve 6P connector.
7. At the EGR valve side, measure resistance between EGR valve 6P connector terminals No. 1 and No. 2.

EGR VALVE 6P CONNECTOR



Terminal side of male terminals


Is there 100 kΩ or more?

YES—Go to step 26.

NO—Go to step 8.

8. Measure resistance between EGR valve 6P connector terminals No. 1 and No. 3.

EGR VALVE 6P CONNECTOR



Terminal side of male terminals


Is there 100 kΩ or more?

YES—Go to step 26.

NO—Go to step 9.

9. Check for continuity between EGR valve 6P connector terminal No. 6 and body ground.

EGR VALVE 6P CONNECTOR



Wire side of female terminals

Is there continuity?

YES—Go to step 10.

NO—Repair open in the wire between the EGR valve and G101 (see page 22-16), then go to step 27.

(cont'd)