

## MOUNTING TO THE SHOCK EXTENDERS

1. Dismount the shock absorber **1**.
2. Make sure that the thread of the shock extenders **3** matches the diameter and thread pitch of the shock.
3. Cut the upper place intended for spanner **4**.
4. Screw the shock extenders **3** using the blue threadlock.
5. Put the polyurethane shim **2** on the shock absorber.
6. Install the shock absorber with stock bushes.

